

iForks-32 5.0

Nr.	Item code	Description	Special instructions	Quantity
D1	WF-2A-100-45-608-USA	Weighing forks FEM 2A 100x45x608 incl. milling USA p.p.		2.0
D2	FS-WF-25-42-IF2-RAL3000	Fork shoes iForks 2500 42" (1067mm), IF2, RAL3000		2.0
D3	LC-2000-350-MR	Load cell 2000, 350 Ohm, multi-range	Serial number is needed when ordering this compoment Load cell can be used to replace 1 of 4 LC-2000-M-350 in non-LFT systems	4.0
D3	LC-2000-M-1000	Load cell 2000 M 1000Ohm	For legal for trade version. Serial number is needed when ordering this compoment	4.0
D4	MP-BOLT-M12-1,5-30-CYL-LOW	Bolt M12 x 1,5 x 30 socket head low head DIN 6912, 8.8		8.0
D5	MP-BOLT-M12-50-CS	Bolt M12 x 50 countersunk DIN 7991		4.0
D6	MP-RING-LC-FIXATION	Loadcell fixation ring		4.0
D7	MP-NUT-M12-LOCKNUT	Nut M12 lock nut din985		4.0
D8	SA-BA-IF2-TR	Subassembly, battery IF2		2.0
D9	SS-TRANSMITTER-LED-IF2	Front panel Transmitter, RAVAS, iForks2.0		2.0
D10	SS-TRANSMITTER-1-IF2	Label fork transmitter, Fork 1, iForks2.0		1.0
D10	SS-TRANSMITTER-2-IF2	Label fork transmitter, Fork 2, iForks2.0		1.0
D11	SAP-HOP-IF2-BAT-LID-PIN	Subassembly, battery cover iForks 2.0 including pin		2.0

Nr.	Item code	Description	Special instructions	Quantity
D12	SAP-HOP-IF2-BAT-LOCK-SPR-R3000	Subassembly, lock-release handle w/ spring, RAL3000		2.0
D13	SAO-EP-IF2-TR-LOWER-SUB	Subassembly, submerged electronics IF2 fork module		2.0
D14	SAP-MP-BOLT-RING-BUSHING-IF2	Subassembly, Bolt with ring and bushing for IF2 housing		1.0
D15	SA-CH-IF2-RAV	Subassembly, charger iFork-32, RAVAS-logo	Includes inserts for EU, UK and US plug sockets	1.0
D16	SAP-HOP-RAV-RAL3000-UPPER	Subassembly, Housing upper RAL3000 (incl. bolts and rings)	Also order the touch panel needed for your system	1.0
D17	FR-32-RAV-HO-RAV-SHIELDED-IF2	Front panel 3200 RAVAS housing shielded, RAVAS logo, iForks		1.0
D18	IN-32	Indicator 3200		1.0
D19	EB-32-REC	Receiver board, i3200 iForks 2.0		1.0
D20	HOP-RAV-RAL9011-LOWER-EXCH-N2	Housing lower part ECO black RAL 9011 exch. battery N2	from 2013. Only for 6v systems	1.0
D20	SA-HOP-RAV-RAL9011-LOWER	Subassembly, Housing lower part ECO black RAL 9011	Only used for 12v versions	1.0
D21	HOP-KIT-RAV-LOWER-BAT-EXCH-N2	Parts set lid+screw housing lower RAL9011 exch. battery	Only for 6v systems	1.0
D22	SAO-HOP-BAT-HOLDER-4XAA	Subassembly, battery holder 4xAA incl. pad printing	Only for 6v systems	1.0
D23	SA-MP-SUP-RAM-CLAMP-BASE	Subassembly, RAM-support clamp		1.0
D24	MP-CP-IF2-FEM2	Cover plate for iForks 2.0 FEM2 RAL 7021		2.0
D25	EB-CON-9/100V-12V-ISOLATED	Converter 9/100v 12v isolated		1.0
D25	EB-CON-100V-12V-120MA	Convertor board 100V 12V 120MA		1.0

Nr.	Item code	Description	Special instructions	Quantity
D26	SA-IN-32-REC-6V	Subassembly, indicator 3200, iForks receiver, 6v (ind. only)		1.0
D26	SA-IN-32-REC-12V	Subassembly, indicator 3200, iForks receiver,12v (ind. only)		1.0
D26	SA-IN-32-REC-9/100V-12V	Subassembly, ind 3200, iForks rec, 9/100V-12V (ind. only)		1.0
D27	MP-BRACKET-RAM-BB	Bracket RAM BB, RAL7021		1.0
D28	MP-BRACKET-RAM-PR-TH-7810	Bracket RAM Martel printer 7810V	Option: printer	1.0
D30	PR-EXT-TH-RAVAS-7810V	Printer Thermal 7810V	Option: printer	1.0
D31	PRP-CA-EXT-TH-RAVAS	Cable printer Custom S /+ 7810 V	Option: printer	1.0
D32	SA-EP-IF2-TR-RAV	Subassembly, Fork module iForks 2.0		1.0
D32	SA-EP-IF2-TR-RAV-M	Subassembly, Fork module iForks 2.0, M version	Option: legal for trade	1.0
D33	EB-OPT-WIFI-XPICO240	Option board WIFI, Xpico 240		1.0
D34	EP-ANTENNE-WLAN-UFL	Antenne WLAN, UFL connector		1.0
D35	EB-OPT-N2-BLT-4.0-CLASSIC	Option board bluetooth 4.0 classic		1.0
D88	PRP-PAP-INT-TH-RAVAS	Printer paper for Plus/S/MPP8250 thermal printer	Option: printer	3.0